User Guide

Dual Band Wireless PCIE Adapter

RNWD-N9003PCE

REV1.1.0
1910020735

CONTENT

Package Contents 1

Chapter 1 Product Overview 2

1.1 Introduction 2

1.2 Features 2

1.3 Hardware Overview 2

Chapter 2 Installation 3

2.1 Hardware Installation 3

2.2 Software Installation 4

Chapter 3 Connect to a Wireless Network 8

3.1 To connect using ROSEWILL WIRELESS N UTILITY 8

3.2 To connect using WPS 11

3.2.1 PBC (Push Button Configuration) method 11

3.2.2 PIN method 13

3.3 To connect using Windows built-in Wireless Utility 15

3.3.1 In Windows XP 15

3.3.2 In Windows Vista 17

3.3.3 In Windows 7 19

3.3.4 In Windows 8 20

3.3.5 In Windows 8.1 22

Chapter 4 Management 25

4.1 Profile 25

4.1.1 Add a profile 25

4.1.2 Modify a profile 29

4.1.3 Delete a profile 30

4.2 Advanced 30

4.3 About 31

Chapter 5 AP Mode (For Windows 7 and Windows 8) 32

Chapter 6 Uninstall Software 34

6.1 In Windows XP/Vista/7 34

6.1.1 Uninstall the Utility software from your PC 34
6.1.2 Uninstall the Driver software from your PC 35
6.2 In Windows 8/8.1.....37
6.2.1 Uninstall the Utility software from your PC.....37
6.2.2 Uninstall the Driver software from your PC.....39
Appendix A: Specifications 37
Appendix B: Glossary 38

Package Contents

Please verify that all the package contents below are available.

- One Rosewill RNWD-N9003PCE Dual Band Wireless PCIE Adapter
- Quick Installation Guide
- One Resource CD for RNWD-N9003PCE, including:
  - Rosewill Wireless N Utility and Drivers
  - User Guide
  - Other helpful information

Make sure that the above items are contained in the package. If any of the above items is damaged or missing, please contact your distributor.

☞ **Note:**

The ‘adapter’ mentioned in this User Guide stands for RNWD-N9003PCE N900 Wireless Dual Band PCI-E Adapter without any explanation.

Chapter 1 Product Overview

1.1 Introduction

The adapter is a dual band 802.11n client device designed to deliver a high-speed wireless performance for your desktop. With a faster wireless connection, you can get a better Internet experience, such as downloading, gaming, and video streaming.

With the 802.11n technology, higher throughput improvements using 3T3R, the RNWD-N9003PCE's auto-sensing capability allows high packet transfer rate of up to 450Mbps for maximum throughput. It has good capability on anti-jamming, and it can also interoperate with other wireless (802.11a/b/g) products. The adapter supports WEP, WPA-PSK/WPA2-PSK and WPA/WPA2 encryption to prevent outside intrusion and protect your personal information from being exposed.

The adapter is easy to install and manage. The Quick Setup Wizard will guide you step-by-step through the installation process and the Rosewill Wireless N Utility will instruct you to quickly set up a wireless connection.

With unmatched wireless performance, reception, and security protection, the RNWD-N9003PCE is the best choice for easily adding or upgrading wireless connectivity to your desktop.

1.2 Features

- Supports dual-band, 2.4GHz or 5GHz
- Seamlessly compatible with 802.11a/b/g/n products
- Experience smoother video streaming and online gaming by choosing the clearer 5GHz band for wireless connections
- Supports 64/128 WEP, WPA/WPA2, WPA-PSK/WPA2-PSK (TKIP/AES), supports IEEE802.1X
- Supports Windows XP 32/64bit, Vista 32/64bit, Windows 7 32/64bit, Windows 8 32/64bit, Windows 8.1 32/64bit
- Supports ad-hoc and infrastructure mode
- Bundled utility provides quick & hassle-free installation

1.3 Hardware Overview

LED status:

Status	Working Status
Off	The driver has not been installed; The radio of adapter has been disabled.
Flashing Slowly	The driver has been installed but no data is being transmitted or received.
Flashing Quickly	Data is being transmitted or received.

Chapter 2 Installation

Please install the PCI-E adapter into your computer before installing the driver and utility software from the Resource CD.

2.1 Hardware Installation

1. Turn off your computer and unplug the power cord from the computer.
2. Open the case and locate an available PCI-E slot. Remove the metal slot cover on the back of the PC. Keep the screws. Turn to your computer manufacturer for instructions if needed.
3. Insert the PCI-E adapter into the PCI-E slot. Make sure that all of its pins have touched the slot's contacts. Once the adapter has been firmly inserted, screw its fastening tab. Then, close your PC case.
4. Insert the power cable back into the computer and turn on your computer.

☞ **Note:**

When the hardware has been successfully installed on your computer, you may be prompted '**Found New Hardware Wizard**' (as shown in Figure 2-1 and Figure 2-2); please click **Cancel**, and then follow the **Software Installation** steps to install driver and utility for your adapter.

Found New Hardware Wizard
Welcome to the Hardware Update Wizard
Windows will search for current and updated software by looking on your computer, on the hardware installation CD, or on the Windows Update Web site (with your permission).
Read our privacy policy
Can Windows connect to Windows Update to search for software?
Yes, this time only
Yes, now and every time I connect a device
No, not this time
Click Next to continue.
< Back
Next >
Cancel

Figure 2-1 Found New Hardware Wizard in Windows XP


Found New Hardware
Windows needs to install driver software for your Ethernet Controller
Locate and install driver software (recommended)
Windows will guide you through the process of installing driver software for your device.
Ask me again later
Windows will ask again the next time you plug in your device or log on.
Don't show this message again for this device
Your device will not function until you install driver software.
Cancel

Figure 2-2 Found New Hardware Wizard in Windows Vista

2.2 Software Installation

The adapter's Setup Wizard will guide you through the installation procedures for Windows XP, Windows Vista, Windows 7 and Windows 8. The procedures in different systems are quite similar, therefore here we use the procedures in Windows 7 as an example.

1. Insert the Resource CD into your CD-ROM drive. Double-click **Computer**, and then double-click the **CD/DVD Drive** where the installation CD was placed. Open **RNWD-N9003PCE** folder, and double-click **Setup.exe** to begin.
2. The **Install Shield Wizard** window will appear. Click **Next** to continue.


Rosewill Wireless Configuration Utility and Driver - InstallShield Wizard
Rosewill
Welcome to the InstallShield Wizard for Rosewill Wireless Configuration Utility and Driver
The InstallShield Wizard will install Rosewill Wireless Configuration Utility and Driver on your computer. To continue, click Next.
< Back
Next >
Cancel

Figure 2-3

3. Choose a setup type. It is recommended to select **Install Rosewill Wireless Configuration Utility and Driver**. Selecting **Install Driver Only** can only install driver. Click **Next** to continue.


Rosewill Wireless Configuration Utility and Driver - InstallShield Wizard
Setup Type
Select the setup type that best suits your needs.
Click the type of setup you prefer.
Install Driver Only
Install Rosewill Wireless Configuration Utility and Driver
Description
Choose this option to install Rosewill Wireless Configuration Utility and driver. This is the recommended option.
InstallShield
< Back
Next >
Cancel

Figure 2-4

4. Click **Change** to specify the destination location for the software or you can leave it default. Click **Next** in the screen below to continue.


Rosewill Wireless Configuration Utility and Driver - InstallShield Wizard
Choose Destination Location
Select the folder where setup will install files.
Install Rosewill Wireless Configuration Utility and Driver to:
C:\...\Rosewill Wireless Configuration Utility
Change...
InstallShield
< Back
Next >
Cancel

Figure 2-5

5. Click **Install** to continue the setup.


Rosewill Wireless Configuration Utility and Driver - InstallShield Wizard
Ready to Install the Program
The wizard is ready to begin installation.
Click Install to begin the installation.
If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.
InstallShield
< Back
Install
Cancel

Figure 2-6

6. The utility and drivers will install. It may take 1~2 minutes.


Rosewill Wireless Configuration Utility and Driver - InstallShield Wizard
Setup Status
The InstallShield Wizard is installing Rosewill Wireless Configuration Utility and Driver
InstallShield
Cancel

Figure 2-7

7. After all the steps above, you will see the screen below. Click **Finish** to complete the setup.


Rosewill Wireless Configuration Utility and Driver - InstallShield Wizard
InstallShield Wizard Complete
InstallShield(R) Wizard has finished Installation. Click Finish to exit the wizard.
< Back
Finish
Cancel

Figure 2-8

8. After installation, the utility configuration page will automatically pop up as shown in the following figure and the icon will appear in your system tray. To connect to a network, please refer to Chapter 3 Connect to a Wireless Network.



Figure 2-9

Chapter 3 Connect to a Wireless Network

With both the hardware and software successfully installed into your computer, you can quickly connect to a wireless network using one of the following methods.

➢ **Method One: To connect using ROSEWILL WIRELESS N UTILITY**

RNWD-N9003PCE uses the ROSEWILL WIRELESS N UTILITY as the management software. The utility provides you an easy interface to connect to a network and to change any settings related to the wireless adapter.

➢ **Method Two: To connect using WPS**

By this method, you can connect to your network quickly on the condition that your Router or access point supports WPS or QSS as is called by some other products.

➢ **Method Three: To connect using Windows built-in wireless utility**

Windows users may use the built-in wireless utility to connect to a wireless network. For specific operations, please go to 3.3 To connect using Windows built-in wireless utility.

3.1 To connect using ROSEWILL WIRELESS N UTILITY

1. After installation, the utility configuration page will automatically pop up on the screen. If the utility page does not pop up, you can also launch the utility by double-clicking the icon on your desktop.



Figure 3-1

2. The **Network** page will display all wireless networks that are available in your area. To connect to a network, simply highlight the wireless network name (SSID) and click **Connect**. If you tick **Connect automatically**, the adapter will automatically connect to your target network next time.



Figure 3-2

3. You will be prompted different windows when you choose wireless network of different security types.

1) Wireless network of **WPA/WPA2-Personal**

If you selected a wireless network of the security type WPA/WPA2-Personal, you will be prompted to enter the password in the security key field, as shown in Figure 3-3. Or you can push the **WPS/QSS** button on your Router (if it features the WPS/QSS function) to quickly build a connection without entering the security key (password).



Figure 3-3

Note:

The security key (password) can be found on the configuration page of your Router or Access Point.

2) Wireless network of **WPA/WPA2-Enterprise**

If you selected a wireless network of the security type WPA/WPA2-Enterprise, you will be prompted to choose a type of authentication, either **Certificate** or **Password**. With **Certificate** as your authentication, you need to select one specific certificate from the drop-down list, as shown in Figure 3-4. With **Password** as your authentication, you should enter the right user name and password in the corresponding field, as shown in Figure 3-5.



Figure 3-4



Figure 3-5

3) Wireless network of None

If you selected a wireless network of **None** (that is, no security is set.), you can get directly connected to this network without any further configuration.

4. Please wait a few minutes for the connection process.



Figure 3-6

5. You have now successfully connected to your network. Click **Close** to enjoy the Internet.



Figure 3-7

6. To view more information about the network currently connected, click **Status** in the tools section and the page will display information such as the network type, channel, rate, etc.



Figure 3-8

3.2 To connect using WPS

WPS (Wi-Fi Protected Setup) function allows you to add a new wireless device to an existing network quickly.

If your wireless Router supports WPS or QSS (Quick Security Setup), you can establish a wireless connection between wireless card and Router using either Push Button Configuration (**PBC**) method or **PIN** method. Three WPS connection methods are listed in the following parts, while the third method is only supported in Windows XP and Windows Vista.

3.2.1 PBC (Push Button Configuration) method

1. Press the WPS or QSS button on the Router. Press the **WPS/Reset** button for 2~3 seconds.



2. Open ROSEWILL WIRELESS N UTILITY and click **WPS** tab. Select **Push the button on my access point or wireless router** and then click **Connect**.


Rosewill
Status
WPS
Network
Profile
Advanced
This application will guide you through configuring your wireless network.
Please choose a method to join a wireless network:
Push the button on my access point or wireless router.
Enter the PIN of my access point or wireless router.
Connect

Figure 3-9

3. The adapter will be connecting to the target network.

Figure 3-10

4. When the following window appears, you have successfully connected to the network.

Figure 3-11

3.2.2 PIN method

There are two ways to configure the WPS by PIN method:

1) Enter the PIN from your Router or AP device.
2) Enter a PIN into your Router or AP device. (This method is only available in Windows XP and Windows Vista.)

Following are the detailed configuration procedures of each way.

3.2.2.1. Enter the PIN from your Router or AP device

1. Open ROSEWILL WIRELESS N UTILITY and click **WPS** tab. Select **Enter the PIN of my access point or wireless router**. In the empty field beside PIN, enter the PIN labeled on the bottom of the Router (here takes 69409325 for example). If you have generated a new PIN code for your Router, please enter the new one instead. Click **Connect** to continue.



Figure 3-12

2. The adapter will be connecting to the target network.

Figure 3-13

3. When Figure 3-11 appears, you have successfully connected to the network.

3.2.2.2. Enter a PIN into your AP device

Note:

This method is only available in Windows XP and Windows Vista.

1. Open ROSEWILL WIRELESS N UTILITY and click **WPS** tab. Select **Enter the PIN of this device into my access point or wireless router**. In the field beside PIN, you will see the PIN value of the adapter which is randomly generated. Click **Connect** to continue.

Rosewill
Status
WPS
Network
Profile
Advanced
WPS
This application will guide you through configuring your wireless network.
Please choose a method to join a wireless network:
Push the button on my access point or wireless router.
Enter the PIN of my access point or wireless router.
Enter the PIN of this device into my access point or wireless router.
PIN: 45888793
Connect

Figure 3-14

2. Open your Router's Web-based Utility and click WPS link on the left of the main menu.Then click **Add device** and the following figure will appear. Enter the PIN value of the adapter in the empty field beside PIN and then click **Connect**.



Figure 3-15

3. When **Connect successfully** appears on the screen (as shown in Figure 3-16), the WPS configuration is completed. Or you can view the adapter's utility page to see whether the connection has been successful (as shown in Figure 3-17).

Figure 3-16

Figure 3-17

3.3 To connect using Windows built-in Wireless Utility

3.3.1 In Windows XP

Windows XP users may use the built-in wireless utility. Follow the steps below.

1. Right-click on the utility icon in your system tray (lower-right corner). Select **Switch to Windows wireless configuration tool**.



Figure 3-18

Or double-click the utility icon to load the utility configuration page. Click **Advanced** in the tools section and then select **Use Windows wireless configuration tool** in the figure shown below. Click **OK** when Figure 3-20 appears to continue.

Figure 3-19



Figure 3-20

2. Right-click on the wireless computer icon in your system tray (lower-right corner). Select **View Available Wireless Networks**.



Figure 3-21

3. The utility will display any available wireless networks in your area. Click on a network (displayed using the SSID) and click the **Connect** button.


Wireless Network Connection 32
Network Tasks
Refresh network list
Set up a wireless network for a home or small office
Related Tasks
Learn about wireless networking
Change the order of preferred networks
Change advanced settings
Choose a wireless network
Click an item in the list below to connect to a wireless network in range or to get more information.
ROSEWILL_A0A1
Security-enabled wireless network (WPA2)
ROSEWILL_0404
Security-enabled wireless network (WPA2)
ROSEWILL_60FE
Security-enabled wireless network (WPA2)
To connect to this network, click Connect. You might need to enter additional information.
WR541
Security-enabled wireless network
SOHO_AT
Connect

Figure 3-22

4. If the network is security-enabled, you will be prompted to enter the key as shown below.

   If not, you will connect to the network directly without entering a key.

Wireless Network Connection
The network 'ROSEWILL_60FE' requires a network key (also called a WEP key or WPA key). A network key helps prevent unknown intruders from connecting to this network.
Type the key, and then click Connect.
Network key:
Confirm network key:
Connect
Cancel

Figure 3-23

3.3.2 In Windows Vista

Windows Vista users may use the built-in wireless utility. Follow the steps below.

1. Open the wireless utility by right-clicking on the wireless computer icon in your system tray as shown in the figure below. Select **Connect to a network**.



Figure 3-24

2. The utility will display any available wireless networks in your area. Highlight the wireless network you would like to connect and then click **Connect**.



Figure 3-25

3. If the network you would like to connect is security-enabled, enter the same security key or passphrase that is on your Router.

   If the network to be connected is not secure, the connection will be built without entering a key.


Connect to a network
Type the network security key or passphrase for ROSEWILL_60FE
The person who setup the network can give you the key or passphrase.
Security key or passphrase:
Display characters
If you have a USB flash drive with network settings for ROSEWILL_60FE , insert it now.
Connect
Cancel

Figure 3-26

4. You have now successfully connected to the network.



Figure 3-27

3.3.3 In Windows 7

Windows 7 users may use the built-in wireless utility. Follow the steps below.

1. Left-click the wireless icon in your system tray (lower-right corner). The utility will display any available wireless networks in your area. Highlight the wireless network (displayed using the SSID) to be connected and then click **Connect**.

Figure 3-28

2. If the network you would like to connect is encrypted, enter the same security key or passphrase that is on your Router. Or push the WPS/QSS button on the Router or access point (You will be prompted to push the button on the window if WPS function is supported as shown in the figure below). If the network to be connected is not secure, the connection will be built without entering a key.



Figure 3-29

3. You have now successfully connected to the network.

Figure 3-30

3.3.4 In Windows 8

Windows 8 users may use the built-in wireless utility. Follow the steps below.

1. Click the icon at the bottom of your screen, and a network list will appear at the right side of your screen. Select your target network, and then click **Connect**.



Figure 3-31

2. If the network is unencrypted, you will directly connect to it.

   If the network is encrypted, enter the password (network security key) and then click **Next** to continue.



Figure 3-32

☞ **Note:**

You can also push the WPS/QSS button on your router as hinted “You can also connect by pushing the button on the router”. Then click **Next** to continue.

3. When Connected appears behind the SSID (as shown below), you have successfully connected to the target network.



Figure 3-33

☞ **Note:**

If the adapter is connected to the network for the first time, you will be asked whether to turn on sharing or connect to devices. Please select “Yes, ...”or “No, ...” according to your Internet environment.


Networks
Network
Do you want to turn on sharing between PCs and connect to devices on this network?
No, don’t turn on sharing or connect to devices
For networks in public places
Yes, turn on sharing and connect to devices
For home or work networks

Figure 3-34

3.3.5 In Windows 8.1

Windows 8.1 users may use the built-in wireless utility. Follow the steps below.

1. Click the icon at the bottom of your screen, and a network list will appear at the right side of your screen. Select your target network, and then click **Connect**.



Figure 3-35

2. If the network is unencrypted, you will directly connect to it.

   If the network is encrypted, enter the password (network security key) and then click **Next** to continue.

Figure 3-36

☞ **Note:**

You can also push the WPS/QSS button on your router as hinted “You can also connect by pushing the button on the router”. Then click **Next** to continue.

3. When Connected appears behind the SSID (as shown below), you have successfully connected to the target network.



Figure 3-37

Note:

If the adapter is connected to the network for the first time, you will be asked whether to connect to devices. Please select “Yes” or “No” according to your Internet environment.


Networks
ROSEWILL_60FE
Do you want to find PCs, devices, and content on this network, and automatically connect to devices like printers and TVs?
We recommend that you do this on your home and work networks.
Yes
No

Figure 3-38

Chapter 4 Management

This section will show you how to configure your RNWD-N9003PCE adapter using the Rosewill Wireless N Utility.

The RNWD-N9003PCE adapter uses the ROSEWILL Wireless N Utility as the management software. The utility provides users with an easy interface to change any settings related to the adapter. Double-clicking on the icon on your desktop will start the utility.

4.1 Profile

Your wireless networks may vary in different places like home, office or coffee shop. With **Profile** management, you can easily save and manage various networks to be connected, saving you the trouble of having to repeat the same configurations. Click **Profile** in the tools section, the following page will appear.



Figure 4-1

4.1.1 Add a profile

To add a profile, click the **Add** button on the bottom of the screen. Then the configuration window will appear.

4.1.1.1. Add a profile in Infrastructure mode

If you are connecting to a wireless router or access point, select **Infrastructure** as the Network. Type in the screen that appears and follow the instructions below to finish the setting.



Figure 4-2



Figure 4-3

The following items can be found on the screen.

- **Profile Name:** Enter a name for your profile (e.g. Home, Office, Coffee Shop). The same name is not allowed. Please also note that no space is allowed between words.
- **SSID:** Select the target network from the drop-down list.
- **Network Type:** Select the network type. If you are connecting to a wireless Router or access point, select **Infrastructure**. If you are connecting to another wireless client such as an adapter, select **ad-hoc**.
- **Security Type:** Select the security type from the list. Four options are available: **WPA-PSK/WPA2-PSK**, **WPA/WPA2**, **WEP** and **None**. The security type should be the same as on your Router or access point, otherwise, you will not be able to build a successful connection. **WPA-PSK/WPA2-PSK** uses a passphrase or key to authenticate your wireless connection. The key must be the exact same key entered on your wireless Router or access point. **None** stands for no security. It's recommended to enable WPA-PSK/WPA2-PSK on your wireless Router or access point before con is configuring your wireless adapter.

☞ **Note:**

You will see Figure 4-2 if you selected the security type **WPA-PSK/WPA2-PSK**; while, if you selected the security type **WPA/WPA2**, Figure 4-3 will be displayed.

- **Encryption Type:** From the drop-down menu, select the encryption type that is the same as on your Router or access point.
- **Security Key:** Enter the passphrase exactly as it is on your wireless Router or access point. Click the **Show characters** box to see the passphrase, or uncheck this box to hide it.
- **Authentication:** Select a type of authentication, either **certificate** or **password**.
- **Certificate:** If you select **certificate** as your **Authentication**, then you need to specify your certificate from the drop-down list here.
- **Start this connection automatically:** Check this box to automatically connect to this network next time.
- **Save:** Click **Save** to save your settings.

Having completed the above settings, the Profile page should look like the following figure. To connect to a desired network, just highlight the network you would like to connect to and click the **Connect** button on the bottom of the window. Then click **OK** in Figure 4-5 to activate the profile.



Figure 4-4



Figure 4-5

4.1.1.2. Add a profile in ad hoc mode (not available in Windows 8.1)

If you are connecting to another wireless client such as an adapter, select ad hoc as the Network Type in the screen that appears and follow the instructions below to finish the setting.



Figure 4-6

The following items can be found on the screen.

- **Profile Name:** Enter a name for your profile e.g. Home, Office, Coffee Shop. The same name is not allowed. Please also note that no space is allowed between words.
- **SSID:** Select the target network from the drop-down list.
- **Network Type:** Select the network type. If you are connecting to a wireless router or access point, select **Infrastructure**. If you are connecting to another wireless client such as an adapter, select **ad hoc**.
- **Band:** This item determines which operating frequency will be used. Two options are available: 2.4GHz and 5GHz. It is recommended that your computers and devices running video and voice applications use the 5Ghz band, while your guest access and computers that are only browsing the web use the 2.4Ghz band.
  - **2.4GHz** - You can use the 2.4GHz band to connect to many classic wireless devices like gaming consoles, laptops, DVRs, ect.
  - **5Ghz** - This band is less crowded and is used for time-sensitive music, video streaming or gaming. Using this band can avoid interference with 2.4GHz networks or noisy devices like cordless phones and microwave ovens.

☞ **Note:**

The choice for **Band** is only available in Windows XP; while in Windows Vista, Windows 7 and Windows 8, by default it only supports 2.4 G network in Ad-hoc mode.

- **Security Type:** Select the security type from the list. Two options are available: **WEP** and **None**. **None** stands for no security. It is recommended that you select WEP to secure your wireless network.
- **Encryption Type:** If you select **None** as the Security Type, the Encryption Type will be **None** accordingly. If you select **WEP** as the Security Type, the Encryption Type will be **Open**.
- **Key Index:** You can select **ASCII** or **Hexadecimal** format on the right. ASCII format stands for any combination of keyboard characters in the specified length. Hexadecimal format stands for any combination of hexadecimal digits (0-9, a-f, A-F) in the specified length.
  - For **64-bit** encryption **-** You can enter 10 hexadecimal digits (any combination of 0-9, a-f, A-F, zero key is not permitted) or 5 ASCII characters.

- For **128-bit** encryption **-** You can enter 26 hexadecimal digits (any combination of 0-9, a-f, A-F, zero key is not permitted) or 13 ASCII characters.

➢ **Security Key:** Enter the passphrase. Click the **Show characters** box to see the passphrase. Unchecking it will hide it.

➢ **Start this connection automatically:** Check this box to automatically connect to this network next time.

➢ **Save:** Click **Save** to save your settings.

Having completed the above settings, the Profile page should looks like the following figure. To connect to a desired network, just highlight the network you would like to connect to and click the **Connect** button on the bottom of the window. Then click **OK** in Figure 4-8 to activate the profile.



Figure 4-7



Figure 4-8

4.1.2 Modify a profile

You may edit an existing profile by clicking the **Modify** button from the Profile page. For instance, you may like to change the profile name from Home to Home1 or you may want to specify another SSID for profile Home. After all the changes, click **Save** to make the changes take effect.



Figure 4-9

4.1.3 Delete a profile

To delete an existing profile, highlight the profile name and click **Remove** on the bottom of the screen or press the Delete button on your keyboard. When the following figure appears, click **OK** to continue.



Figure 4-10

4.2 Advanced

The following configurations can be made on the **Advanced** page:

1) To select wireless configuration tool.
   Here you can decide which tool to use, either the ROSEWILL Configuration Utility or the Windows wireless configuration tool. (This option is available only in Windows XP.)

2) To switch to another wireless network adapter.
   Here you can switch to another adapter installed in your computer. The adapters successfully installed in your computer will be listed in the drop-down list if the adapters are supported by this utility.

3) To switch to SoftAP mode. (This option is available in Windows 7, Windows 8 and Windows 8.1.)
   Once enabled, the adapter will be able to work as an AP.

4) To change the power save mode. The default option is OFF.

Figure 4-11

4.3 About

The About screen gives you some information about the Driver and Utility versions of the adapter. Right-click the icon in your system tray and select **About** from the list.



Figure 4-12



Figure 4-13

Chapter 5 AP Mode (For Windows 7 and Windows 8)

In SoftAP mode, the adapter will work as an AP. (This function is available in Windows 7 and Windows 8.

Suppose that only one computer in your house can access the Internet for various reasons like only one WLAN port is available on your wired broadband Router, however, other wireless-capable devices also want to share the Internet. Then the adapter can be configured as an AP under the SoftAP mode, saving you the trouble of having to get a separate access point or a Router.

With this feature, a computer can use a single physical wireless adapter to connect as a client to a hardware access point while at the same time acting as a software AP allowing other wireless-capable devices to connect to it.

1. To switch to this mode, right-click on the utility icon in your system tray and select **Switch to SoftAP mode**.



Figure 5-1

2. Click **OK** when prompted to confirm the setting.



Figure 5-2

3. The **SoftAP** icon then will appear beside **Advanced** icon in the utility.



Figure 5-3



Figure 5-4

- **SoftAP mode:** Select to enable or disable the function.
- **Internet Connecting Share (ICS):** Specify a connection through which devices connected to your AP can access the Internet.
- **SSID:** Enter the name for your softAP (for example, Jone) so that others can know which AP is yours when trying to connect to it.
- **Security Type:** The security type here is set to be WPA2-PSK which is based on 802.11i and uses AES (Advanced Encryption Standard) instead of TKIP. It was designed to improve the security features of WEP. WPA2-PSK uses a passphrase or key to authenticate your wireless connection. You needn't make any configuration here.
- **Encryption Type:** The encryption type here is set to be AES.
- **Security Key:** Enter the Key in the field to make your AP security enabled. It is recommended that you specify another key instead of the default key 12345678. Only by entering the corresponding key can other computers establish a successful connection with your AP.
- **IP Address:** Here displays the IP address of the SoftAP.

Having completed the above settings, click **Apply**; then Figure 5-4 will pop up, where you click **OK** to make SoftAP mode take effect.

Chapter 6 Uninstall Software

6.1 In Windows XP/Vista/7

The software uninstall steps are similar in Windows XP, Windows Vista, and Windows 7. Here we just use Windows 7 as an example.

6.1.1 Uninstall the Utility software from your PC

1. On the Windows taskbar, click the **Start** button, click **All programs** →**ROSEWILL**, and then click **Uninstall-ROSEWILL Wireless N Utility**.



Figure 6-1 Uninstall Utility

2. Click **Yes** to start uninstalling the utility software from your PC.


Rosewill Wireless Configuration Utility - InstallShield Wizard
Do you want to completely remove the selected application and all of its features?
Yes
No

Figure 6-2

3. It may take a few minutes to undergo the whole un-installation process.


Rosewill Wireless Configuration Utility - InstallShield Wizard
Setup Status
InstallShield Wizard is removing the Rosewill Wireless Configuration Utility
InstallShield
Cancel

Figure 6-3

4. Click **Finish** when the figure below appears.



Figure 6-4

6.1.2 Uninstall the Driver software from your PC

1. On the Windows taskbar, click the **Start** button, click **All programs→ROSEWILL**, and then click **Uninstall-ROSEWILL RNWD-N9003PCE Driver**.



Figure 6-5 Uninstall Driver

2. Click **Yes** to start uninstalling the driver software from your PC.


Rosewill Wireless Configuration Utility and Driver - InstallShield Wizard
Do you want to completely remove the selected application and all of its features?
Yes
No

Figure 6-6

3. It may take a few minutes to undergo the whole un-installation process.



Figure 6-7

4. Click **Finish** when the figure below appears.



Figure 6-8

6.2 In Windows 8/8.1

The software uninstall steps are similar in Windows 8 and Windows 8.1. Here we just use Windows 8 as an example.

6.2.1 Uninstall the Utility software from your PC

1. Enter the **Metro** interface , right-click any blank place in the Metro interface, then **App Bar** will appear below the Metro interface, click **All apps**. Find the **ROSEWILL** application, and click **Uninstall- ROSEWILL Wireless N Utility**.

Figure 6-9

2. Click **Yes** to start uninstalling the utility software from your PC.


Rosewill Wireless Configuration Utility-InstallShield Wizard
Do you want to completely remove the selected application and all of its features?
Yes
No

Figure 6-10

3. It may take a few minutes to undergo the whole un-installation process.



Figure 6-11

4. Click **Finish** when the figure below appears.



Figure 6-12

6.2.2 Uninstall the Driver software from your PC

1. Enter the **Metro** interface ,right-click any blank place in the Metro interface, then **App Bar** will appear below the Metro interface, click **All apps**. Find the **ROSEWILL** application, and click **Uninstall-ROSEWILL RNWD-N9003PCE Driver**.



Figure 6-13

2. Click **Yes** to start uninstalling the driver software from your PC.


Rosewill Wireless Configuration Utility and Driver-InstallShield Wizard
Do you want to completely remove the selected application and all of its features?
Yes
No

Figure 6-14

3. It may take a few minutes to undergo the whole un-installation process.



Figure 6-15

4. Click Finish when the figure below appears.



Figure 6-16

Appendix A: Specifications

Normal	
Interface	PCI-E x1
Standards	IEEE802.11a; IEEE802.11b; IEEE802.11g; IEEE802.11n; IEEE802.1x
Operating System	Windows XP, Windows Vista, Windows 7, Windows 8, Windows 8.1
Throughput	450Mbps (Maximal)
Radio Data Rate	11a: 6/9/12/18/24/36/48/54Mbps 11b: 1/2/5.5/11Mbps 11g: 6/9/12/18/24/36/48/54Mbps 11n: 450Mbps (2.4GHz), 450Mbps (5GHz)
Modulation	11a: OFDM 11b: CCK, QPSK, BPSK; 11g: OFDM; 11n: QPSK, BPSK, 16-QAM, 64-QAM
Media Access Protocol	CSMA/CA with ACK
Data Security	WEP, WPA / WPA2, WPA-PSK / WPA2-PSK
Frequency*	2.4 ~ 2.4835 GHz, 5.180 ~ 5.240 GHz, 5.260 ~ 5.320 GHz, 5.745 ~ 5.825 GHz
Spread Spectrum	Direct Sequence Spread Spectrum (DSSS)
Safety & Emissions	FCC, CE, WIFI, IC, NCC, WHQL

Environmental and Physical	
Working Temperature	0℃~40℃ (32℉~104℉)
Storage Temperature	-40℃~70℃(-40℉~158℉)
Working Humidity	10% ~ 90% RH, Non-condensing
Storage Humidity	5% ~ 90% RH, Non-condensing

* 1. Only 2.412GHz~2.462GHz is allowed to be used in USA, which means only channel 1~11 is available for American users to choose.

* 2. Rules on the use of 5GHz band channels may vary according to different national laws.

Appendix B: Glossary

- **802.11a -** specification for wireless networking at 54 Mbps using OFDM modulation and operating in radio band at 5GHz.
- **802.11b -** The 802.11b standard specifies a wireless product networking at 11 Mbps using direct-sequence spread-spectrum (DSSS) technology and operating in the unlicensed radio spectrum at 2.4GHz, and WEP encryption for security. 802.11b networks are also referred to as Wi-Fi networks.
- **802.11g -** specification for wireless networking at 54 Mbps using direct-sequence spread-spectrum (DSSS) technology, using OFDM modulation and operating in the unlicensed radio spectrum at 2.4GHz, and backward compatibility with IEEE 802.11b devices, and WEP encryption for security.
- **802.11n -** 802.11n builds upon previous 802.11 standards by adding MIMO (multiple-input multiple-output). MIMO uses multiple transmitter and receiver antennas to allow for increased data throughput via spatial multiplexing and increased range by exploiting the spatial diversity, perhaps through coding schemes like Alamouti coding. The Enhanced Wireless Consortium (EWC) was formed to help accelerate the IEEE 802.11n development process and promote a technology specification for interoperability of next-generation wireless local area networking (WLAN) products.
- **Ad hoc Network -** An ad hoc network is a group of computers, each with a Wireless Adapter, connected as an independent 802.11 wireless LAN. Ad hoc wireless computers operate on a peer-to-peer basis, communicating directly with each other without the use of an access point. Ad hoc mode is also referred to as an Independent Basic Service Set (IBSS) or as peer-to-peer mode, and is useful at a departmental scale or SOHO operation.
- **DSSS -** (**D**irect-**S**equence **S**pread **S**pectrum) **-** DSSS generates a redundant bit pattern for all data transmitted. This bit pattern is called a chip (or chipping code). Even if one or more bits in the chip are damaged during transmission, statistical techniques embedded in the receiver can recover the original data without the need of retransmission. To an unintended receiver, DSSS appears as low power wideband noise and is rejected (ignored) by most narrowband receivers. However, to an intended receiver (i.e. another wireless LAN endpoint), the DSSS signal is recognized as the only valid signal, and interference is inherently rejected (ignored).
- **FHSS -** (**F**requency **H**opping **S**pread **S**pectrum) **-** FHSS continuously changes (hops) the carrier frequency of a conventional carrier several times per second according to a pseudo-random set of channels. Because a fixed frequency is not used, and only the transmitter and receiver know the hop patterns, interception of FHSS is extremely difficult.
- **Infrastructure Network -** An infrastructure network is a group of computers or other devices, each with a Wireless Adapter, connected as an 802.11 wireless LAN. In infrastructure mode, the wireless devices communicate with each other and to a wired network by first going through an access point. An infrastructure wireless network connected to a wired network is referred to as a Basic Service Set (BSS). A set of two or more BSS in a single network is referred to as an Extended Service Set (ESS). Infrastructure mode is useful at a corporation scale, or when it is necessary to connect the wired and wireless networks.
- **Spread Spectrum -** Spread Spectrum technology is a wideband radio frequency technique developed by the military for use in reliable, secure, mission-critical communications systems. It is designed to trade off bandwidth efficiency for reliability, integrity, and security. In other words, more bandwidth is consumed than in the case of narrowband transmission, but the trade off produces a signal that is, in effect, louder and thus easier to detect, provided that the receiver knows the parameters of the spread-spectrum signal being broadcast. If a receiver is not tuned to the right frequency, a spread-spectrum signal looks like background noise. There

are two main alternatives, Direct Sequence Spread Spectrum (DSSS) and Frequency Hopping Spread Spectrum (FHSS).

- **SSID -** A **S**ervice **S**et **Id**entification is a thirty-two character (maximum) alphanumeric key identifying a wireless local area network. For the wireless devices in a network to communicate with each other, all devices must be configured with the same SSID. This is typically the configuration parameter for a wireless PC card. It corresponds to the ESSID in the wireless Access Point and to the wireless network name. *See also* Wireless Network Name and ESSID.
- **WEP -** (**W**ired **E**quivalent **P**rivacy) **-** A data privacy mechanism based on a 64-bit or 128-bit or 152-bit shared key algorithm, as described in the IEEE 802.11 standard. To gain access to a WEP network, you must know the key. The key is a string of characters that you create. When using WEP, you must determine the level of encryption. The type of encryption determines the key length. 128-bit encryption requires a longer key than 64-bit encryption. Keys are defined by entering in a string in HEX (hexadecimal - using characters 0-9, A-F) or ASCII (American Standard Code for Information Interchange - alphanumeric characters) format. ASCII format is provided so you can enter a string that is easier to remember. The ASCII string is converted to HEX for use over the network. Four keys can be defined so that you can change keys easily.
- **Wi-Fi -** A trade name for the 802.11b wireless networking standard, given by the Wireless Ethernet Compatibility Alliance (WECA, see http://www.wi-fi.net), an industry standards group promoting interoperability among 802.11b devices.
- **WLAN -** (**W**ireless **L**ocal **A**rea **N**etwork) - A group of computers and associated devices communicate with each other wirelessly, which network serving users are limited in a local area.
- **WPA -** (**W**i-Fi **P**rotected **A**ccess) **-** A wireless security protocol uses TKIP (Temporal Key Integrity Protocol) encryption, which can be used in conjunction with a RADIUS server.